



861


866 867



871



856




1


23

24

4



5




13

14

20

27



26

21

18

19

8

2

3


9

11

10

12

15



5

6

7

25

28

25

25

17

16

22

Parts List for FS1800D Type 1

Item Number	Part Number	Description	Qty Required
1	5145507-03	SCREW	1
2	5101984-00	BEARING WASHER	1
3	5101752-00	WASHER	1
4	5146441-00	SIDE COVER	1
5	5145486-07	CLAMSHELL SET	1
6	5100035-03	SPRING	2
7	5146420-02	SCREW	1
8	5100117-00	SPRING	1
9	5100115-00	BIT RELEASE RING	1
10	497927-02	RETAINING CLIP	1
11	5100776-00	HUB CAP	1
12	000000-00	No Longer Available	1
13	5145510-00	SWITCH, VSR	1
14	5103036-00	RING,MOTOR	1
15	5145584-00	MOTOR & GEARBOX	1
16	90508941	NAMEPLATE	1
17	5146442-00	SUPPORT COVER	1
18	5145492-01	TOP COVER	1
19	5146445-00	SHIFTER BUTTON	1
20	5145488-00	ACTUATOR FWR/REV	1
21	148354-03	BIT CLIP	2
22	5146444-00	SUPPORT PLATE	1
23	5146443-01	COVER PLATE	1
24	5145507-02	SCREW	2
25	5146420-01	SCREW	4
26	607918-41	SCREWDRIVER BIT	2
27	5100034-00	TERMINAL BLOCK	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for FS1800D Type 1

Item Number	Part Number	Description	Qty Required
28	5146420-00	SCREW	1
856	5148271-00	BELT CLIP	1
861	5102001-05	KITBOX	1
866	90506197	BATTERY PACK	1
867	5102026-00	BATTERY CAP	1
871	90504598	DUAL CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.