

PARTS LIST

for




UNDERCOUNTER DISHWASHER

Models:

JDB8700AWS1 (Stainless)

**FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS**


DOOR PANEL PARTS



DOOR PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10418362	Installation, Instructions
	W10490712	Energy Guide
	W10418360	Use & Care Guide, English/French
	W10418361	Use & Care Guide, Spanish
	W10455257	Tech Sheet, English
	W10455258	Tech Sheet, French
2		Arm, Hinge
	8534854	Left Hand
	8534853	Right Hand
3	W10321447	Barrier, Vapor Assembly
4	W10316572	Screw
5		Toe Panel
	8558252	Black
6		Panel, Front (Includes Items 4, 10, 11, & 16)
	W10409495	Stainless
7	W10276608	Screw, Set
8		Screw
	302868	Black
9		Handle Assembly
	W10409496	Stainless
10	8564951	Stud, Mounting
11	W10319007	Light, Pipe
12	W10385107	Insulation, Toe Panel
13	W10315897	Insulation, Front Panel
14	W10194911	Bracket, Control Panel
15	3400071	Screw
16		Nameplate
	W10214168	Stainless
17	W10350437	Insulation, Three Layer
18		Access Panel
	W10195777	Black
19	8269016	Clip, Ground


CONTROL PANEL AND LATCH PARTS



CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)
	W10418327	Stainless
2	W10195237	Clip, Control
3	W10315814	Jumper, 4 Wire
4	W10348409	Screw
5	W10380262	Latch Assembly (Includes Switch)
6	W10403605	Control, Electronic
7	W10462395	Brace, Connector
8	W10195836	Light, Status
9	W10462393	Box, Connector


INNER DOOR PARTS



INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10309090	Screw
2	8281217	Screw
3	W10467367	Inner Door & Mastic Assembly (Also Order Item 6)
4	W10497235	Seal, Door Bottom
5	W10409521	Dispenser, Assembly
6	W10195007	Seal, Console/Door
7	W10380183	Wiring Harness
8	W10177098	Screw, Door
9	W10462232	Bracket, Dispenser
10	W10195837	Barrier, Vapor
11	3400071	Screw
12	W10195028	Duct, Vent
13	W10469574	Vent Assembly
14	W10195032	Deflector, Vent


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch
2	8531412	Hose
3	W10195536	Inlet, Water (Also Order Item 4)
4	8531323	Gasket
5	W10213825	Nut, Water Inlet (Also Order Item 4)
6	371505	Clamp, Hose
7	W10316814	Fill Valve Assembly
8	304392	Screw
9	W10195039	Switch, Overfill Control
10	W10195035	Housing, Overfill (Also Order item 11)
11	8531743	Gasket, Flat Assembly
12	W10195038	Nut, Standpipe
13	W10195036	Float & Retainer Assembly
14	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
15	370445	Clamp, Hose
16	W10481093	Drain Loop with Check Valve Assembly


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10511186	Tub Assembly (Also Includes Heater Assembly)
2	3400924	Retainer, Push In
3	W10300924	Gasket, Tub
4	W10082838	Plug, Tub
5	W10300779	Strike, Latch
6	3400014	Screw, Grounding
7	W10179427	Seal, Cabinet
8	W10195367	Sound Insulation, Bottom
9	W10084086	Door Balance Assembly
10	3367670	Screw
11	8269145	Bracket, Undercounter
12	3400074	Screw
13	W10339563	Thermostat
14	W10348411	Screw
15	8268977	Wheel, Leg
16	W10304228	Leveler, Leg
17	3378128	Washer, Pronged Cup
18	8270020	Spring, Door Balance
19	3400892	Screw
20	8268991	Cover, Terminal Box
21	W10158291	Cable, Door
22	W10292870	Shield, Thermostat
23	304666	Retainer
24	8573239	Shield, Tub Sound
25	W10300703	Bracket, Thermostat
26		Spacer, Tub/Brace
	W10195630	Left Hand
	W10195631	Right Hand
27	W10275523	Shield, Side Tub
28	8539404	Tie, Wire
29	W10398392	Support Assembly, Rear
30	W10337661	Strain Relief


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10314568	Motor (Also Order Items 9 & 11)
2	W10195086	Motor, Isolator
3	W10455271	Cover, Outlet
4	W10455268	Sump With Seal
5	9741232	Screw
6	W10195360	Screen
7	W10453957	Sprayarm, Lower
8	W10393351	Filter Cup, Assembly
9	W10445975	Hose Asembly (Includes 2 Clamps)
10	W10455260	Motor & Sump Assembly
11	W10195068	Grommet
12	W10348407	Screw
13	W10372113	Tab, Sump
14	W10531320	Motor, Drain
15	8269144	Hose, Drain
16	W10476221	Disc, Diverter
17	W10476222	Motor, Diverter
18	8269146	Clamp, Hose
19	W10134017	Indicator, Optical Wash
20	W10169167	Clamp, Hose


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340745	Feed Tube Assembly (Includes Item 2)
2	W10327455	Sprayarm, Third Level
3	W10195329	Seal, Sprayarm
4	W10380275	Manifold
5	W10453933	Sprayarm, Upper

HEATER PARTS




HEATER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10329322	Heater Element Assembly (Includes Item 2)
2	717273	Washer (Rubber)
3	8268548	Nut, Heater Element
4	3400931	Nut, Speed
5	W10343251	Shield, Heater Probe

NOTE: If heater
element is removed, it
must be replaced.


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10194861	Dishrack, Upper
2	W10418314	Adjuster Arm
3	W10238406	Clip, No Flip
4	W10056298	Handle, Dishrack (Rear)
5	W10267076	Clip, Dispenser Guard
6		Track, Assembly
	W10311156	Right Hand
	W10311157	Left Hand
7	W10056297	Handle, Dishrack (Front)
8	W10309090	Screw
9		Housing Adjuster
	W10418316	Right Hand
	W10418315	Left Hand
10	W10418320	Clip Lock
11	W10418323	Position Adjuster
12	W10418321	Adjuster Cover
13	W10418322	Strap, Tether Adjuster
14	W10208697	Cupshelf
15	W10238407	Mount, Cupshelf
16	W10194862	Tine, Fold Down
17	W10238404	Clip, Pivot
18	W10238405	Positioner, Dual


LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10056350	Dishrack, Lower
2	W10195416	Wheel & Transport Assembly
3	W10311153	Basket, Silverware
4	W10056351	Tinerow
5	W10238411	Retainer, Tinerow
6	W10238412	Pivot, Tine Row
7	W10311149	Lid, Basket (Right)
8	W10311150	Lid, Basket (Left)
9	W10311151	Lid, Basket (Center)

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Track Assembly
	W10195240	Right Hand
	W10195238	Left Hand
2	8564852	Stop, Track
3	8564899	Mount, Track
4	W10409522	Rack Assembly (Third Level)
5	W10418356	Basket

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171657	Black
	8171656	White
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		CUSTOM PANEL & TRIM KIT
	8212489	Black
		ARCHITECT II HANDLES
	W10195735A	Black
	W10195736A	White
	W10195737A	Biscuit/Bisque
	W10195738A	Stainless Steel
		DRAIN HOSE
	3385556	12 Ft.
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis
		MOISTURE BARRIER KIT
	4396277	Kit

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque
	4396603	Meteorite

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
	4396838	White
	4396840	Gray
	4396854	Silver Atlantis